


Water Pump: Service and Repair


Water Pump Replacement (4.8L, 5.3L, and 6.0L Engines)

Removal Procedure


1. Drain the cooling system.




2. Loosen the air cleaner outlet duct clamps at the following locations:
 - Throttle body
 - Mass Airflow/Intake Air Temperature (MAF/IAT) sensor
3. Remove the radiator inlet hose clip from the outlet duct.
4. Remove the air cleaner outlet duct.
5. If necessary, remove the engine sight shield.




6. Remove the radiator vent inlet hose from the radiator hose clips.




7. Position the inlet hose clamp at the water pump.
8. Remove the inlet hose from the water pump.
9. Remove the fan blade.



11. Position the outlet hose clamp at the water pump.
12. Remove the outlet hose from the water pump.




13. Position the surge tank outlet hose clamp at the water pump.
14. Remove the surge tank outlet hose from the water pump.



15. Position the heater inlet hose clamp at the water pump.

16. Remove the heater inlet hose from the water pump.




17. Remove the water pump bolts.

18. Remove the water pump and gaskets.

19. Discard the water pump gaskets.

Installation Procedure



Important: All gaskets surfaces are to be free of oil or other foreign material during assembly.


1. Install the water pump and NEW gaskets.

Notice: Refer to Fastener Notice in Service Precautions.


2. Install the water pump bolts.

2.1. Tighten the bolts a first pass to **15 Nm (11 ft. lbs.)**.


- 2.2. Tighten the bolts a final pass to **30 Nm (22 ft. lbs.)**.




3. Install the heater inlet hose to the water pump.
4. Position the heater inlet hose clamp at the water pump.




5. Install the surge tank outlet hose to the water pump.
6. Position the surge tank outlet hose clamp at the water pump.




7. Install the outlet hose to the water pump.
8. Position the outlet hose clamp at the water pump.
9. Install the accessory drive belt.




10. Install the fan blade. Refer to Fan Replacement.
11. Install the inlet hose to the water pump.
12. Position the inlet hose clamp at the water pump.



13. Install the engine vent inlet hose to the radiator hose clips.
14. If necessary, install the engine sight shield.



15. Install the air cleaner outlet duct.



16. Align the arrow at the throttle body end of the duct with the throttle body attaching stud.
17. Install the radiator inlet hose clip to the outlet duct.
18. Tighten the air cleaner outlet duct clamps at the following locations:
 - Throttle body
 - MAF/IAT sensorTighten the clamps to **7 Nm (62 inch lbs.)**.
19. Fill the cooling system.